

# Sanitize Footbath Flormat

## SHOES SANITIZING FOOTBATH



**NEW  
VERSION**  
**BETTER LOCK  
THE ABSORBENT PAD**



### Features

Clean the shoes on Sanitizing Footbath  
Scratch resistant  
No PVC

### Application

- Entrance door
- Screening point
- Hospital
- Hotel
- Restaurant
- Office building
- Spa
- Shops
- Clean Room
- Kitchen
- Laundry
- Convenient store

# Sanitize Footbath Flormat





## Recommendations

- Clean and dry the floor before placing Flormat-Sanitize Footbath for better stay stable on the floor.
- Fill sanitizer in the footbath until absorbent pad is soaked approximately 0.5 – 1 liter
- For absorbent pad : needle punch(Type A) place the ribbed surface on top.
- Refill sanitizer every 2- 3 hours and depended on traffic.
- Clean and dry the Flormat-Sanitize Footbath and absorbent pad everyday for hygiene and life extension
- If "Dettol" is applied, white stain may occur on the rubber.
- **Do not use sanitizer contain Sodium Hypochlorite (e.g. Haiter).**
- Keep the floor and surrounding area dry while using to prevent slipping

## Cleaning instruction

- Spray with pressure water hose.
- Clean with soft brush with mild detergent. No bleaching agent.
- Dry in shade. Avoid direct sunlight.
- Store the dried mats by roll or flat. Should not be folded
- Not recommended to laundry.



<b>Product data</b>	Material of mats	: 100% Nitrile rubber (NBR)	
	Material of Absorbent pad (refill)	: type A: Needle Punch fabric : type B: Non-woven fabric	
	Size		
	Finished	: 50 x 80 cm	
	Sanitizing footbath (W x H x D)	: 39.5 x 70.5 x 0.4 cm	
	Border	: 6.5 ± 0.5cm	
	Absorbent pad	: 39 x 69 cm	
	Capacity of Sanitizing Footbath:	: Approx. 0.5 Litre	
	Total weight:	: Approx. 4.6 kg/sqm (1.85 kg/piece)	
	Total Height:	: Approx. 5 mm	
	Colour	:	
	Sanitizing footbath	: Black	
	Absorbent pad	: Type A: Needle Punch - Brown : Type B: Non-woven - Black	
	Surface Flammability	: Pass ASTM D 2859 (> 1 inch)	
	High-Traction	: Pass NFSI 101-C (Slip and Trip resistance on clean and dry floor)	

\*For all mats we reserve for the right of production-related tolerance +/- 5% in size.

Fabric colour and rubber properties may change due to type and concentration of sanitizer.

**The Mill International Pte Ltd** | t: 65-6846 7200 | e: enquiry@themill-int.com | w: flormat.com  
35 Tannery Road, Ruby Industrial Complex, #06-06 Tannery Block, Singapore 347740

